

## Short description for using the SiS RTM 4002 X with the DK option

The modified RTM 4002 X has an additional reed switch which does not interfere with the normal activation reed switch. This switch is placed just beside the display at the sensor side of the instrument. It is in parallel with the standard tilt switch.

The external trigger unit is placed on the instrument over the marking above the upper left corner of the display. The horizontal part of the marking must be visible through the slit of the trigger unit and the vertical part must be in parallel with the side of the trigger unit.

Please note, that the instrument is still sensitive for reversing because of the active tilt switch.

The triggering is as follows:

To prepare the trigger unit, pull the cord with the magnetic bar and fix the bar with the pin of the ripcord. Hold the instrument with the sensor head pointing downwards and enter the sample mode (see RTM 4002 X User Manual). The instrument is now prepared for sampling. When the magnet of the trigger unit is released with the ripcord, it will activate the instrument and start sampling.



SiS Sensoren Instrumente Systeme GmbH  
Mühlenkoppel 12  
D-24222 Schwentinental, Germany  
Tel: +49-431-79972-0  
Fax: +49-431-79972-11  
Email: [info@sis-germany.com](mailto:info@sis-germany.com)  
WWW: <http://www.sis-germany.com>